ETL.

eurodib

# INDUCTION PLATE
# PLAQUE A INDUCTION

# INSTRUCTION MANUAL
# MANUEL D' UTILISATION

MODEL:P3D
MODÈLE:P3D

SPECIFICATION:
Item no.: P3D
Power Rate: 1600W
Voltage: 120V/60Hz
Temperature: 150°F - 450°F

**Important safeguards**

To avoid damage or danger by improper use, the instruction for use should be read and followed carefully. Save the instructions together with the guarantee card and receipt for further reference. If you give the appliance to other persons, also supply them with the instruction for use.

- Connect your appliance to a grounded power socket with appropriate voltage (120V, 60Hz). Do not connect other electrical appliances at the same socket and do not use multiple sockets.
- Make sure that the mains installation is providing enough power to run this appliance. See the rating plate of the appliance to proof this.
- Caution! When operating electrical appliances (such as hot plates and hot pans) please beware that high temperatures are achieved which may cause injuries. Please use handles or pot cloth if necessary. Inform other people using this appliance as well.
- To avoid overheating do not directly place the appliance next to a wall or under a wall cupboard. Make sure there is sufficient safe distance towards item which may easily melt or inflame. Do not store any objects which may easily melt or inflame near the appliance. Do not block the air supply and ventilation of the appliance.
- After each use let the device cool down sufficiently and clean it with a slightly damp cloth to prevent the surface from damage. Always handle with care. Do not use any abrasive cleaners or cleaning pads to avoid damage. Do not use any sharp or hard objects while cleaning the device. Do not leave any food residues dry on the surface of the appliance.
- Do not use the appliance while standing on a wet ground or if your hands or appliance are wet. To avoid any risk of electrical shock do not immerse cord, plug or appliance in water or other liquid. Do not pour or drip any liquid at the motor base or cord. When liquids are spilled on the motor base, immediately switch OFF. Unplug and dry the motor base with care.
- Never wash the appliance and power cord in the dishwasher.
- Do not use outdoors, household use only.
- Do not place any empty containers, pots or any metal object on the device while in operation. Do never overheat the cookware.
- Do never place any ferromagnetic objects near the appliance (i.e. TV, radio, credit cards, cassettes etc.)
- Use the item only on heat-resistant surfaces, such as stone or ceramics and do not place the appliance near or on hot surfaces or near other strong heating devices.
- Never place or use the appliance on the carpets or cloth or other objects which are easily inflammable.

- Do not place any kindly of tissues or cloth or other objects which are easily inflammable under or in the appliance to avoid the risk of the fire or electrical shock. Never store inflammable products near the appliance, they could catch fire.
- Never leave the appliance unsupervised when in use near young children. Young children are not aware of any danger that can be caused by electrical appliances (especially when using heating devices). Therefore, supervision and caution is necessary when the appliance is operated by or near children. Never let young children be unattended or handle with electric appliance!
- The appliance must be stored at a place which is unapproachable for children.
- Do not let unattended or play with plastic foils or other packing parts. Danger of suffocation!
- Make sure to store the appliance on a dray clean place, safe from frost, excessive strain(mechanical or electrical shock, heat, moisture) and out of the reach of children.
- Do not operate it when appliance or any parts of it are damaged to avoid all risk. The appliance is damaged when there are any cracks, excessively broken or frayed parts, distortions or leaks, or when the gear on the motor vase stalls or sticks. In this case, immediately stop to use the appliance and return the entire appliance (including any parts and accessories) to an authorized service centre for examination and repair.
- To unplug the appliance never pull on the cord, take the plug directly at its housing and unplug it. To avoid electrical shock or short circuit never let the cord hand into water, other liquids or over the washing basin.
- **Caution! Danger of burning and fire! Never touch the heated surface with hand or other parts of shin. Never place other objects than cookware on the appliance when it is connected to the power supply. Do not place empty pots or other empty cookware on the appliance when it is operate.**
- In case of flames never try to extinguish with water but take a damp cloth.
- Do not let cord hand over edge of table or counter, or in a heated oven.
- A short power-supply cord (or detached power supply cord) is to be provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord.
- Longer detached power supply cord or extension cord are available and may be used if care is exercised in their use.
- If a longer detached power supply cord or extension cord power-supply cord is used, A- The marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance, and
  B- The cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over unintentionally.
- Do not cook on Broken Cook-top-If cook-top should break, cleaning solutions and spillovers may penetrate the broken cook-top and create a risk of electric shock.
- Do not place a sheet of paper between the pot or the pan and the unit. The paper may get burnt.
- Items with a magnetic field, such as: radios, televisions, automatic-banking cards and cassette tapes, can affect the unit.
- This appliance has a polarized plug (one blade is wider than other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the



plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt modify the plug in any way.

**Before the first use**

- remove all the packaging components.
- Before using for the first time clean unit surface with moist cloth.
- See: CLEANING INSTRUCION
- When it is switch on for the first time, the appliance may smell and emit some smoke. This is normal; the grease that may have adhered to the element during manufacturing is burning off. We therefore recommend that you heat up the appliance for a few minutes (ventilation the room during this period). Repeat for 2-3 times, then the smoke will disappear (this is no sign of danger).

**Operation Instructions**

Induction cooking plates are designed in consideration of state of the art standards

- Before turning on the power, make sure the cookware is on the ceramic plate with ingredients inside.
- The cookware has to be ferromagnetic. Always place it centred onto the cooking field.
- To avoid any risks do not place very big ferromagnetic objects (i. e. griddles) onto the cooking zone of the ceramic field.
- Do not block the ventilation slots of device. This may overheat the device. Keep minimum distance of 10cm to walls or other items.
- Make sure that the mains connection cable is not damaged or squashed beneath the device. Make sure that the mains connection cable does not come into contact with sharp edges and/or hit surface.

**Technical operation mode and Advantages of the Induction hotplates**

With induction hotplates, an electric voltage is applied on a conductor spool beneath the glass ceramics. This creates magnetic fields, which directly heat up the bottom if the cookware through a physical effect.

This means saving time and energy, because contrary to common hotplate, the cookware is heated up, not the heating element and the glass ceramics. Due to the technical characteristics described above, another advantage is the very short start-up cooking time.

In addiction, the heat supply promptly adapts to changed settings and can be controlled in small steps. The induction hotplate reacts to change setting just as fast as gas stove, as the energy reaches the pot immediately without having to heat up other materials first. The induction technology combines this fast reaction with the basic advantage of electricity, meaning being able to exactly adjust the heat supply.

Additional advantages of an induction hotplate:

- As the hotplate is only heated up indirectly via the bottom of the cookware, over spilling food cannot stick and burn and there is hardly any danger of burns for the user. The glass ceramic is only heated up by the hot cookware.
- Once you take the cookware off the hotplate, the device automatically switches to standby mode.
- The device detects whether suitable cookware is placed on the hotplate. If this is not the case, no energy is transmitted.

Operating of the device

- Insert the plug into a suitable outlet.
- To turn the power on, press the ON/OFF button once. The power light will turn a steady red and heating will begin.
- To select the proper heat setting, press the +/- key, until the correct heat setting is achieved. (Defaults=5)
- To select temperature setting, press the" Temp" button (defaults=270℉), the temperature light will turn a steady red, and press the +/- key, until the correct temperature setting is achieved. （The temperature is between 150℉ to 450℉， 150，180，210，240，270，300，330，360，390, 420, 450℉）.
- To select automatic timer setting, press the" Timer" button (defaults =0min), the timer light will turn a steady red, and press the +/- key, until the correct timer setting is achieved. You will be able to select the operating time in increasing 5 minutes, and reducing 1 minute. (The timer is between 0 to 150 mins)
- After cooking is completed, press the ON/OFF button again to turn off the unit.
- After the cooking time reach 150 mins, the LED will show "EE" and sound, and then the unit will enter the standby mode. Press the ON/OFF button to restart the unit.

**Notice:**

- If using the unit in TEMP or HEAT Function, not setting the TIMER Function, but when the unit is used 150 mins, the LED display shows EE code and sound. The unit will stop automatically.
- If using the unit in TEMP or HEAT Function 10 mins, and then set the TIMER, the max Timer is 140 mins. During timer operation, you can change the duration at any time with the arrow keys.

NOTE: The power will completely shut off with 9 second if either (a) the wrong type of cookware is applied or (b) no cookware is placed on the unit.

**USABLE AND NON-USABLE UTENSILS:**

Compatible Pans:

- Steel or cast iron, enameled iron, stainless steel, flat-bottom pan/pots with diameter of 12 to 26 cm.
- Non- compatible Pans:
  Heat-resistant glass, ceramic container, copper, aluminum pan/pots. Rounded-bottom pan/pots with the base measuring less than 12cm.



**Cleaning and maintenance**

- Before cleaning always switch OFF the device and unplug, wait for the device to cool down.
- Clean the device after each use to remove food residues.
- Wipe off the glass-ceramic plate and the plastic surface with a slightly damp cloth.
- Make sure that no water can come into the devise.
- To avoid any danger or risk of the electrical shock, never use abrasive cleaners, cleaning pads or any sharp objects (i.e. metal scouring pads). Always handle the appliance with care and without any force.
- Use of additional cleaning liquids is recommended for induction cooling-plate to extend their lifetime.
- Do not use any petrol products to clean the device to avoid damaging the plastic and the control panel.
- Do not use any flammable acidy or alkaline materials or substances near the device, as this may reduce the service life of the device and cause deflagration when the device is switch on.
- Make sure that the bottom of the cookware does not scrap across the glass field.
- When not in use store the device in a dry place.

## Error Code List:

- If LED-display shows the error code, please reference to the solution as following.

| Error Code | Cause and Solution |
|---|---|
| E1 | Voltage is under 95V |
| E2 | Voltage is over 145V |
| E3 | The accessory and spare parts are damaged, please contact the nearest authorized service facility for trouble shooting, repair and adjustment. |
| E4 | The accessory and spare parts are damaged, please contact the nearest authorized service facility for trouble shooting, repair and adjustment. |
| E5 | The accessory and spare parts are damaged, please contact the nearest authorized service facility for trouble shooting, repair and adjustment. |
| E6 | The cooking temperature is over 390℉ in the function mode "TEMP". After the unit has been cooled down, the unit would be automatic switches to standby mode. |
| E7 | Ventilation blocked, heat can not be blew out of the machine smoothly, it causes device inside over-heat. Please keep a minimum distance of 5 to 10 cm from the device to walls or other items. Please power off to eliminate the wrong record and let the unit cool down, and then re-plug the power cord and restart the unit. |
| E8 | The cooking temperature is over 300℉.If use the function mode "Power" to cook, the max temperature is 300℉.If the cooking temperature is over 300℉ in this mode, the unit would be appeared the error. Please power off to eliminate the wrong record and let the unit cool down, and then re-plug the power cord and restart the unit. If you would like the cooking temperature is over 300℉, please use the function mode "TEMP", the max temperature is 390℉. |
| E9 | Using cookware without magnetic bottom or the diameter of the bottom is less than 12cm (5"). Please use cookware with magnetic and flat bottom. Such as iron or cast iron cookware, or cookware with 18/0 stainless steel bottom. The bottom should have a diameter of 12 to 26cm (5" - 10"). After using suitable cookware, the unit will restart automatically |
| EE | The total cooking Timer reaches 150 mins. After reaching 150 mins, the LED shows "EE" and sound, the device automatically goes into standby mode. Please press ON/OFF button to restart the unit. |



Caractéristiques :

Référence produit : P3D

Puissance : 1600W

Voltage : 120V/60Hz

Température : 150℉~450℉

## Précautions de sécurité

- Avant la première utilisation de l'appareil, lire attentivement et respecter les instructions de ce mode d'emploi. Conserver le mode d'emploi, le certificat de garantie et le bon d'achat de l'appareil ensemble. En cas de cession de l'appareil à autrui, céder également le mode d'emploi et tous les doucments cooresepondants. En cas de constatation d'endommagement ou de mauvais fonction-nement au débaiiage de l'appereil, consulter notre
- Brancher l'appareil individuellement uniquement sur une prise sécurisée d'alimentation de courant alternatif 120V/ 60Hz, avec prise de terre. Ne brancher aucun autre appareil sur la même prise – ne pas utiliser de rallonge életrique pour cet appareil.
- Vérifier que la tension du sectur életriques soit suffisante pour alimenter l'appareil.
- ATTENTION : L'utilisation d'appareils chauffants életriques dégage de fortes températures pouvant présenter des risque de brûlure notamment avec une plaque de cuisson chaude, poêle chaude ou huile brûlante! Avertir tous les utilisateurs des risques liés à l'utilisation de cet appareil.
- Pour éviter les bouffées de chaleur, ne pas mattre l'appareil directement près des murs ou sous des armories suspendues. Laisser suffisamment d'espace et de zone de sécurité autour de l'appareil, loin des objets inflammables ou susceptibles de fondre. Ne jamais poser d'objets facilement inflammables à proximité de l'appareil ou sur le plan de travail sur lequel l'appareil repose. Ne jamais boucher les orifices d'aspiration d'air ou d'aération de l'appareil.
- **Ne jamais** laisser couler de l'eau ou autre liquide sur ou sous l'appareil, ni pour le nettoyage, ni pour toute autre raison. **Ne jamais** plonger l'appareil dans l'eau ou tout autre liquid, ne jamais arroser l'apqreil de liquid, ne jamais nettoyer l'appareil, le cordon électrique ou la prise au lavevaisselle. DEBRANCHER IMMDIATEMENT l'appareil en cas de débordement de liquide sur l'appareil ou d'innondation pendant l'utilisation.
- Laisser suffisamment refroidir l'appareil après chaque utilisation avant de le nettoyer à l'aide d'un tissu humide doux pour préserver les surfaces délicates. Ne jamsis utiliser d'objets métalliques tranchants, de pailles de fer ou de produits récurrents pour le nettyage des surfaces en verre ou en matière plastique. Ne pas laisser de résidus d'aliment bûlés sur la plaque.
- Ne jamais utiliser l'appareil s'il est mouillé, ni quand le sol ou son environnement sont mouillés, ni avec les mains humides pour éviter les risques d' électrocution.
- Ne pas poser d'objets magnétiques à proximité de l'appareil tels que radio, TV, carte de crédit, cassette.
- Ne pas déplacer l'appareil avec une casserole/poêle dessus.
- Si possible, ne pas utiliser votre plaque à l'extérieur, un suage domestique intérieur est

seul recommandé.

- Ne pas faire chauffer de récipient vide, ne pas laisser surchauffer les récipients.
- Ne pas poser d'objets métalliques tels que couteau, cuillère, boîte de conserve, papier d'alluminium, couvercle de casserole sur l'appareil pendant son fonctionnement.
- Utiliser l'appareil uniquement sur une surfance résistante à la chaleur telle que la pierre par exemple.
- Ne jamais utiliser l'appareil sur un tapis, une nappe ou autre objet facilement inflammable.
- Ne poser aucune serviette, aucun sopalin, papier, plastique, vêtement ou autre objet facilement inflammable à proximité ou sur l'appareil en fonctionnement, entre les casseroles et les plaques pour éviter tout risque d'incendie ou d' électrocution.
- Ne jamais laisser cet appareil, ni d'autres appareils életriques en particulier les appareils de cuisson, sans surveillance pendant l'utilisation surtout en présence d'enfants. Les petits enfants ne sont pas conscients des risques que présente l'utilisation d'appareils électriques. Ne jamais laisser les petits enfants évoluer autour de l'appareil ou l'utiliser sans surveillance !
- Pour des raisons de sécurité, ne pas conserver les emballages ( sachet plastique, carton, styropore, etc.) à la portée des enfants.
- Utiliser et conserver l'appareil uniquement dans un endroit sec à l'abri d'humidité, du gel ou d'autres dangers tels que chute, choc, surchanffe, infiltration d'humidité à l'intérieur de l'appareil, etc. Toujours conserver l'appareil et tous ses accessoires hors de potée des enfants.
- Ne plus utiliser l'appareil en cas d'endommagement complêt ou partiel de l'appareil, de mauvais fonctionnement ou apres uns chute, un choc, une surchauffe, une infiltration d'humidité, etc. Un endommagement de l'appareil se reconnaît également par l'apparition de fissures ou d'éclats, un aspect usé et des déformations quelconques. Apporter alors l'appareil pour entretien ou réparation dans un service de réparation agréés par le fabricant.
- Ne pas poser l'appareil à proximité d'une autre source de chaleur puissante.
- Ne pas laisser pendre le cordon. Ne pas laisser le cordon entrer en contact avec un objet tranchant ou une source de chaleur.
- Ne pas tirer sur le cordon pour débrancher l'appareil mais saisir directement la fiche avant de la retirer de la prise murale.
- Ne jamais plonger l'appareil, le cordon ou la prise dans l'eau ou autre liquide pour éviter tout risque d' électrocution.
- **Attetion : danger de brûlure et d'incendie ! Quand l'appareil est en fonctionnement ou branché au secteur électrique, ne jamais y poser les mains, poser ou placer momentanément des récipients de cuisson vides. Ne jamais mattre de casserole/poêle vide sur une plaque allumée.**
- En cas d'incendie provoqué par une surchauffe éventuelle, ne jamais essayer d' éteindre ie feu avec de l'eau. Ettoufer la flammable avec un linge mouill.
- Ne pas laisser le cordon pendre au dessus d'un bord de table ou toucher une surface chaude.
- Un cordon court est monté sur la plaque pour éviter tout nceud ou autre inconénient.



- Un cordon plus long peut être utilisé et devra être installé avec les précautions d'usage.
- Si un cordon plus long est utilisé :
  A- Le nouveau cordon doit pouvoir supporter autant d'intensité que l'original.
  B- Ne pas laisser pendre un cordon long d'un comptoir où un enfant peut le tirer.
- Ne pas cuisiner avec une plaque céramique cassée. Par la fissure, des liquides pourraient pénétrert dans la partie électrique de l'appareil et créer un court circuit.
- Ne pas faire de cuisson avec une feuille de papier posée entre la plaque et la casserole, le papier pourrait finir par brûler.
- Des émetteurs ou lecteurs de champ magnétique tels que radios, télévisions, cartes de crédit et cassettes audio ou vidéo peuvent créer des interférences avec l'appareil.
- L'appareil est livré avec une prise polarisée. Pour réduire le risque d'un choc électrique, il est recommandé d'utiliser une sortie électrique polarisée. Une prise polarisée possède des fiches différentes, l'une est plus large que l'autre.

## Avant la première utilisation

- Enlever tous les emballages.
- Poser l'appareil sur un plan de travail plat, sec et résistant à la chaleur.
- Chauffer l'appareil à température maximale pendant quelques minutes pour éliminer le film de protection et les résidus de fabrication éventuels. La fumée et l'odeur disparaissent après 2-3 répétitions de ce processus.

## Mode d'emploi et conseils

Ces plaques à induction ont été conçues les normes plus récentes :

- Avant d'allumer votre plaque à induction, assurez vous d'y avoir déposé votre casserole avec ses ingrédients.
- Le récipient de cuisson utilisé doit être à induciton ( poêle ou casserole induciton) et toujours placé au centre de la plaque. Pour des raisons de sécurité, éviter de poser des objets induction trop grands ( plaque de four par exemple ) sur la zone vitrocéramique.
- Selon les connaissances actuelles, l'utilisation de plaque à induction conformément au mode d'emploi devait être sans risque pour les personnes porteuses de pacemaker. Un danger reste toutefois probable en cas d'utilisation erronnée de l'appareil ou de conditions d'utilisation inappropriées. Aussi, il est conseillé aux personnes porteuses de pacemaker de consulter un médecin à ce sujet avant de travailler avec une plaque de cuisson à induction.
- Poser l'appareil sur une surface plane, stable et sèche. Ne jamais poser l'appareil sur des matériaux inflammables tels que nappe, papier ou autres objets identiques.
- Ne jamais boucher ou couvir les orifices d'aspiration d'air et d'aération de l'appareil ( risque de surchauffe !) Toujours maintenir une distance de sécurité d'env. 10cm par rapport aux murs ou autres objets.
- Toujours veiller au bon état du cordon d'alimentation. Veiller à ce qu'il ne soit pas bloqué sous l'appareil. Veiller à ce que le cordon d'alimmentation n'entre pas en contact avec une quelconque source d'humidité, source de forte chaleur ou avec un objet tranchant.

| | |
|---|---|
| | consulter votre revendeur le plus proche et déposer votre matériel en service après-vente. |
| E6 | La température de cuisson est supérieure à 450°F pour article. Après avoir refroidi, l'appareil devrait passer automatiquement en mode « veille ». Après être restée au mode d'attente pendant 3 minutes, l'appareil s'éteint; on peut le rallumer. |
| E7 | La ventilation est bloquée. La chaleur ne peut pas partir l'appareil. Respectez la distance minimum de 5 à 10 cm - (2" - 4") entre l'appareil et les murs ou d'autres objets. Débranchez l'appareil pour éliminer le message d"erreur et permettre le refroidissement de la plaque puis rebrancher le cordon et redémarrer l'appareil. |
| E8 | La température de cuisson dépasse 300°F. La température maximale proposée par le mode "HEAT" est de 300 °F. Si la température dépasse 300°F, un message d'erreur apparaît. Débranchez l'appareil pour éliminer le message d'erreur et permettre le refroidissement de la plaque puis rebrancher le cordon et redémarrer l'appareil. Si vous désirez cuire à plus de 300°F, veuillez utiliser le mode « TEMP » qui propose des températures de chauffe allant jusque 450°F. |
| EE | Le temps total de cuisson dépasse 150min. Si le temps dépasse 150min, le display indique "EE" et vous entendez un bip, l'appareil devrait passer automatiquement en mode « veille ». Puis redémarrer l'appareil. |